


For best results, locate a suitable site for your fountain that is leveled and provides pleasing viewing angles.
Note: Always follow local electrical codes and use a 110V GFCI protected outlet.

4714F

1. Locate a suitable site for your fountain. Site should be level and provide a pleasing viewing angle. You should always follow local electrical codes and use a GFCI protected outlet.
2. Locate the 7714 Base on firm leveled surface.
3. Position 4714 St. Francis Top on top of 7714.
4. Attach tubing to pump, slip in the Restrictor onto the tubing.
5. Place Pump in the cavity immediately behind the 4714 St. Francis figure and connect to Pipe.
6. Gently push the Brass Pipe into the hole in the fountain wall above the pot.
7. St. Francis's hand is supplied as a separate piece and it is attached using the silicone adhesive supplied in the connection kit. Apply the silicone adhesive around the mounting surface of the hand and then insert it into the socket in the arm. Adjust the position and let the adhesive set.
8. Fill 4714 St. Francis' pot with water, to about one inch below its rim.
9. Plug pump into GFCI protected outlet.
10. Adjust Restrictor as necessary to control flow.



IMPORTANT - WINTER CARE:

Do not allow water to collect and freeze in fountain bowl(s) or shell(s). Do not allow fountain pieces to sit in a pool of ice. Disassemble entire fountain and pump and store indoors during the winter season.

If you cannot store your fountain indoors during the winter season, you must at least protect it from ice collection or exposure: first, remove the statue(s) and pump, storing them inside if possible. Next, locate the drain plug on the underside of bowl(s) or shell(s). Remove the drain plug to drain any water "trapped" between the walls of the bowl(s) or shell(s). Then fill the bowl(s) or shell(s) with an absorbent material, such as burlap, blankets, etc. Finally, cover the entire fountain with a Henri Fountain Cover. Should condensation droplets form on the inside of the cover, the material will absorb them.

By following these simple and sensible precautions during the winter season, you will protect your fountain for years of beauty and enjoyment!

CAUTION: The use of Chlorine or Chlorine Bleach may damage the finish of your fountain. When cleaning your fountain, it is best to test the cleaning agent on an underside or back surface to determine the agent's suitability. We recommend the use of a mild, non-abrasive treatment, such as Henri Lime Remover and Preventer. To avoid foaming, thoroughly rinse the fountain to remove the entire cleaning agent.