


SETTING UP THE 4944F2



Make sure to place your fountain on a firm and level surface which will not settle. Note: Always follow local electrical codes and use a 110V GFCI protected outlet. Do not let children climb on fountain.



CK302

- PS1 (24-16H)
- Pump Adapter 1/2" (24-132H)
- Tubing No Kink 1/2" X 10" (04-34H)
- Restrictor R1 (20-06H)
- Adapter 1/2" X 1/2" Barb (15-45)

IMPORTANT – WINTER CARE
 Winter ice build-up can cause damage to concrete statuary. Follow these tips to reduce winter weathering to your fountain:

- * Disconnect power to pumps and lights.
- * Remove plugs/stoppers in all fountain bowls to open drains and let all moisture out. Keep drains open throughout winter.
- * Cover with a Henri fountain cover. Keep tight and do not let snow or water collect in sagging areas.
- * Do not allow snow or ice to build up on or against the concrete. Remove snow before it turns to ice. Do not use antifreeze, salt or chemical ice removers as these may damage concrete.

Online Resources
 Products: www.henristudio.com/products
 FAQs: www.henristudio.com/faq
 Warranty: www.henristudio.com/warranty
 Contact : www.henristudio.com/contact-us

Caution: Using Chlorine or Chlorine Bleach or water coloring additives or salt may damage the finish of your fountain.

04/12/2024