



Large Two Tier Leonesco Fountain 5216F6

1. Locate a suitable site for your Large Two Tier Leonesco Fountain. Site should be level and provide a pleasing viewing angle. You should always follow local electrical codes and use a GFCI Protected outlet.

NOTE: this is a tall vertical sculpture and care should be taken to provide a level surface before assembly is started, as a slight angle will be noticeable and can affect the fountain's water action.


2. Locate the 7217 Large Pedestal in the center of your site with the cord notch closest to your power source. Level as necessary.

3. Thread the 2" X 12" Stand Pipe into the 6218 Large Lion Face Bowl. Pass the power cord down through the Stand Pipe leaving approximately 12-14" of cord inside the bowl. Install a rubber stopper over the power cord and insert it into the top of the stand pipe. The rubber stopper has a slit in it, Spread the stopper apart at the slit and slide the cord into the hole in the center of the stopper.


4. Attach the 3/4" adapter to the pump output. Connect the 3/4" piece of NKT (No Kink Tubing) to the pump outlet with a clamp. Place the pump in the center of the Large Lion Face Bowl. Place the 7216 Medium Pedestal over the Stand Pipe and pump. Lay the NKT over the top. Center and level as necessary.

5. Thread the 1" male x 3/4" barb adapter into the bottom of the 6217 Bowl. Then thread the 1" male x 1/2" barb adapter into the inside floor of the bowl. Set the bowl on the 7216 pedestal, connecting the tube to the barb underneath and securing with a clamp.

6. Push the 1/2" tube onto the barb inside the bowl. Set the 7219 Riser in the bowl, around the tube. Lower the 5216 Finial top toward the Riser, pushing the 1/2" tubing up inside the Finial before gently setting it on the Riser. Read your pump instructions, fill with water, and start up your fountain.



Bushing/Barb
Adapter Assembly



5216F6

IMPORTANT- WINTER CARE:

Do not allow water to collect and freeze in fountain bowl(s) or shell. Do not allow fountain pieces to sit in a pool of ice. Disassemble entire fountain and pump and store indoors during the winter season.

If you cannot store your fountain indoors during the winter season, you must at least protect it from ice collection or exposure. Protect your fountain during the winter season: first remove the statue(s) and pump, storing them inside if possible. Next, locate the drain plug on the underside of bowl(s) or shell. Remove drain plug to drain any water "trapped" between the walls of the bowl(s) or shell. Then fill the bowl(s) or shell with an absorbent material such as burlap, blankets, etc. Finally, cover the entire fountain with a Henri Fountain Cover. Should condensation droplets form on the inside of the cover, they will be absorbed by the material.

By following these simple and sensible precautions during the winter season, you will protect your fountain for years of beauty and enjoyment!