SET UP INSTRUCTION for 5738F1

1. Prepare a firm and level surface on which to place your new fountain. Always follow local electrical codes. Make sure to connect to a safe GFCI circuit. Use help with this heavy fountain.

2. Place the fountain stone piece on its prepared location.

3. Set the pump in the fountain and push its power cord out the wider hole, out the back of the fountain. Thread the $\frac{1}{2}$ " male x $\frac{1}{2}$ " barbed adapter into the top of the pump. Thread the $\frac{3}{4}$ " male x $\frac{1}{2}$ " barb adapter into the center coupling hole as shown. Push one end of the water tube onto the pump adapter. Slip the flow restrictor onto the tube and tighten just enough to keep it in place. Push the other end of the tube onto the adapter in the fountain.


4) Set the AB871L light on the cast-in round platform found half way up the inside front of the concrete basin. Push its power cord out the back hole along with the pump's cord.

5) Install the rubber stopper around the two power cords by opening the slits and pushing them into the inner holes in the stopper. Then press the stopper firmly in place in the large exit hole which you pushed the cords out through.

6) Twist the copper spout onto the mounting pipe at the top of the "Tree of Life" design wall.

7. Read your pump and light instructions. Fill the basin with water. Plug in the transformer and pump to a GFCI power circuit. (*If the pump does not immediately work, there may be an "airlock" in the impeller chamber. Simply unplug and plug in a few times and it should start.*) Once you see the water run from the spout, you may adjust the flow restrictor to create the amount of flow you prefer.

Csd



IMPORTANT – WINTER CARE

Winter ice build-up can cause damage to concrete statuary. Follow these tips to reduce winter weathering to your fountain:

* Disconnect power to pumps and lights.* Do not allow snow or ice to build up on or

- against the concrete.
- * Remove plugs in all fountain bowls to open drains and let all moisture out. Keep drains open throughout winter.

* Place an absorbant material like burlap, blankets, etc. inside vases/bowls and cover all with a Henri fountain cover.

* Do not use salt or chemical ice removers as these may damage concrete.