


Avalon Fountain (5772F2)



1) Place the pump in the basin, drape the pump cable out the back of the basin. Affix the smaller of the two included adapters to the top of the pump.

2) Place the light in the top bowl and run the cable down through the 5772A, connect the cable to one of the three connection spots on the splitter. Place the AB871L in the basin, and connect the cable to a second connection spot on the splitter. Leave the third connection spot on the splitter capped. On the opposite side of the splitter, connect the light extension cable and drape the cable over the back side of the basin.

3) Screw the large adapter onto the bottom of the 5772A, allowing the light cable to pass through the slot in the adapter. Press the included tubing onto the large adapter, and onto the adapter affixed to the pump.

4) Affix the copper spills to each level of the fountain, largest at the top, medium in the middle, smallest on the bottom. Lay a generous, continuous bead of silicone across the concrete where will spill will go, and press the spill into place.

Questions? Email
ProductSupport@HenriStudio.com

Caution: The use of Chlorine or Chlorine Bleach or water coloring additives may damage the finish of your fountain.

Make sure to place your fountain on a firm and level surface which will not settle. Note: Always follow local electrical codes and use a 110V GFCI protected outlet. Do not let children climb on fountain.

IMPORTANT – WINTER CARE

Winter ice build-up can cause damage to concrete statuary. Follow these tips to reduce winter weathering to your fountain:

- * Disconnect power to pumps and lights.
- * Remove plugs/stoppers in all fountain bowls to open drains and let all moisture out. Keep drains open throughout winter.
- * Cover with a Henri fountain cover. Keep tight and do not let snow or water collect in sagging areas.
- * Do not allow snow or ice to build up on or against the concrete. Remove snow before it turns to ice. Do not use antifreeze, salt or chemical ice removers as these may damage concrete.