




For best results, locate a suitable site for your fountain that is leveled and provides pleasing viewing angles.
 Note: Always follow local electrical codes and use a 110V GFCI protected outlet.

4032F4

1. Locate a suitable site for your Small **Regal Tier Fountain**. Site should be leveled and provide a pleasing viewing angle.
2. Locate the 6033 Basin in the center of your site. Bowl must be leveled. Cord relief hole on the 6033 Basin will indicate the back of fountain.
3. Attach the ADAPTER 1/2"MNPT X 3/4"BARB to Pump. Place PS1.5 Pump inside of the 6033.
4. Slip the cord through the stopper and into the hole in the casting, then press the stopper down until water tight. (leave 6"-8" of cord to the inside of the 6033 Basin)
5. Attach NKT3/4" X 14" Tubing to adapter on Pump. Slip R1 Restrictor over Tubing.
6. Attach one ADAPTER 3/4" X 3/4" BARB to the top of the 6034 Basin and one at the bottom.
7. Carefully set 6034 Basin on to of 6033 Basin and attach Tubing from Pump to bottom adapter attached to 6034 Basin.
8. Attach NKT3/4" X 4" Tubing to Barb that is at top of 6034 Basin.
9. Place 4032 Finial on top of 6034 Basin and slip NKT3/4" X 4" Tubing through its center.
10. Fill 6033 Basin with water. Plug Pump into GFCI protected outlet.
11. Adjust R1 Restrictor as necessary to control flow.



IMPORTANT - WINTER CARE:

Do not allow water to collect and freeze in fountain bowl(s) or shell(s). Do not allow fountain pieces to sit in a pool of ice. Disassemble entire fountain and pump and store indoors during the winter season.

If you cannot store your fountain indoors during the winter season, you must at least protect it from ice collection or exposure: first, remove the statue(s) and pump, storing them inside if possible. Next, locate the drain plug on the underside of bowl(s) or shell(s). Remove the drain plug to drain any water "trapped" between the walls of the bowl(s) or shell(s). Then fill the bowl(s) or shell(s) with an absorbent material, such as burlap, blankets, etc. Finally, cover the entire fountain with a Henri Fountain Cover. Should condensation droplets form on the inside of the cover, the material will absorb them.

By following these simple and sensible precautions during the winter season, you will protect your fountain for years of beauty and enjoyment!

CAUTION: The use of Chlorine or Chlorine Bleach may damage the finish of your fountain. When cleaning your fountain, it is best to test the cleaning agent on an underside or back surface to determine the agent's suitability. We recommend the use of a mild, non-abrasive treatment, such as Henri Lime Remover and Preventer. To avoid foaming, thoroughly rinse the fountain to remove the entire cleaning agent.