


For best results, locate a suitable site for your fountain that is leveled and provides pleasing viewing angles.
 Note: Always follow local electrical codes and use a 110V GFCI protected outlet.

CAUTION: The installation of this fountain is only intended to be done **BELOW GROUND!!!**

4165F

1. Locate a suitable site for your **Apex Rock Fountain**.
2. Dig a hole the depth and shape of the UG110 Basin
3. Drop the UG110 Basin inside the hole, which will house the connection kit And Pump. You will also be covering the Basin with the UG110 Tray. The Apex Rock will sit on top of the UG110 Basin.
4. Back fill any space outside of the Basin and under the rim of Basin. This is an important step to keep Basin firm and strong.
5. Thread Adapter 3/4" MNPT X 1" BARB to PS450 Pump. Place Pump in the Basin, with its cord exiting through one of the Tray openings.
6. Connect NKT 1" X 42" Tubing to Adapter on Pump. Use Clamp to secure Tubing.
7. Feed Tubing through middle hole on the Tray and place Tray on top of Basin.
8. Thread Adapter 1" MNPT X 1" BARB to inner part of the Apex Rock.
9. Carefully place the Apex Rock on its side next to Tray. Attach Tubing to Adapter in the Apex Rock and used Clamp to secure it. Lift Apex Rock and center it.
10. Cover the Tray with stone until they match the level of the ground around it. Fill Basin with water.
11. Plug pump into GFCI protected outlet.
12. Adjust Restrictor as necessary to control water flow.
13. Place decorative stone to camouflage tray - Use one bag of Henri Mexican River Pebbles (#ROCK75 - Not included).



IMPORTANT - WINTER CARE:

Do not allow water to collect and freeze in fountain bowl(s) or shell(s). Do not allow fountain pieces to sit in a pool of ice. Disassemble entire fountain and pump and store indoors during the winter season.

If you cannot store your fountain indoors during the winter season, you must at least protect it from ice collection or exposure: first, remove the statue(s) and pump, storing them inside if possible. Next, locate the drain plug on the underside of bowl(s) or shell(s). Remove the drain plug to drain any water "trapped" between the walls of the bowl(s) or shell(s). Then fill the bowl(s) or shell(s) with an absorbent material, such as burlap, blankets, etc. Finally, cover the entire fountain with a Henri Fountain Cover. Should condensation droplets form on the inside of the cover, the material will absorb them.

By following these simple and sensible precautions during the winter season, you will protect your fountain for years of beauty and enjoyment!

CAUTION: The use of Chlorine or Chlorine Bleach may damage the finish of your fountain. When cleaning your fountain, it is best to test the cleaning agent on an underside or back surface to determine the agent's suitability. We recommend the use of a mild, non-abrasive treatment, such as Henri Lime Remover and Preventer. To avoid foaming, thoroughly rinse the fountain to remove the entire cleaning agent.