


For best results, locate a suitable site for your fountain that is level and provides pleasing viewing angles. Note: Always follow local electrical codes and use 110V GFCI protected outlet.

## 5636F Classic Lion Pillar Fountain

- Place 6636 on firm, flat location.
- Fit pump cord through 2" wide stand pipe and also through the bottom of the base, pulling out for later connection to power source. Tightly thread stand pipe into bowl. Insert rubber stopper around cord and into top of stand pipe.
- Place 7636 square pump cover over pump and stand pipe, as shown. Attach one end of tubing to the pump and tighten it with a clamp.
- Place tall 5636C column on pump cover, pulling tubing up and through as you do.
- Insert barbed adapter underneath the 5636B lion face spouting section. As you place it on top of the 5636C column, attach the long tube to the barb underneath and clamp.
- Thread tee into inside floor of 5636B. Attach the two short tubes to the tee. Slip flow restrictors onto the tubes as shown.
- Thread the other adapter under the 5636A top piece. Then hold it over the lion section and attach one of the tubes from the tee to this barb. As you lower the top, make sure the loose tube does not spray directly out a lion mouth, as this may leave your water display unbalanced.
- Place the four 6636A splash receptacles in the bowl around the pump cover and column. Place a copper splash reduction screen on top of each receptacle.
- Fill with water and plug pump into a GFCI protected outlet to begin the fountain. To increase the water flow from the 5636A, tighten the restrictor of the loose tube on the 5636B.



### IMPORTANT- WINTER CARE:

Do not allow water to collect and freeze in fountain bowl(s) or shell. Do not allow fountain pieces to sit in a pool of ice. Disassemble entire fountain and pump and store indoors during the winter season. If you cannot store your fountain indoors during the winter season, you must at least protect it from ice collection or exposure. Protect your fountain during the winter season: first remove the statue(s) and pump, storing them inside if possible. Next, locate the drain plug on the underside of bowl(s) or shell. Remove drain plug to drain any water "trapped" between the walls of the bowl(s) or shell. Then fill the bowl(s) or shell with an absorbent material such as burlap, blankets, etc. Finally, cover the entire fountain with a Henri Fountain Cover. Should condensation droplets form on the inside of the cover, they will be absorbed by the material. By following these simple and sensible precautions during the winter season, you will protect your fountain for years of beauty and enjoyment!

CAUTION: the use of Chlorine or Chlorine Bleach may damage the finish of your fountain. When cleaning your fountain, it is best to test the cleaning agent on an underside or back surface to determine the agents suitability. We recommend the use of a mild, non abrasive detergent. To avoid foaming, thoroughly rinse the fountain to remove all of the cleaning agent.