

SET UP INSTRUCTION FOR 5991F1

1) Prepare a suitable location for your new fountain. The fountain needs the support of a firm and level surface.

2) Always follow local electrical codes. Make sure to connect to a safe GFCI circuit.


3) Thread the preassembled nozzle into the top of the pump. For the best presentation, it is advised to place the light on top of the pump also. For this, Stonecasters has supplied some putty-like caulking tape. Apply the caulking tape to the top of the pump and press the base of the light into it.

4) Place the fountain on its prepared location. Place the pump/light/nozzle assembly inside the fountain. Push the two power cords down through the hole in the fountain floor. Gently and slightly tip the fountain to pull the cords out the back, aligning them under the groove provided for the cords. (**Do not tip the fountain forward** against its rock front base. Instead, you may tip it all the way down on its back, pull the cords out, and then with the help of others, straighten it back up.)

5) Inside the fountain, place the rubber stopper around the power cords. Then press the stopper into the hole, leaving about 1/8" of it above the floor level.

6) Read your pump and light instructions. Connect the light power cord to the transformer provided and plug in the transformer and pump to enjoy your fountain. If the pump does not immediately begin working, there may be an "airlock" within the impeller chamber. Simply unplug and plug back in a few times and it should start.

7) Save this instruction and make sure to winterize according to details below.



IMPORTANT – WINTER CARE

Winter ice build-up can cause damage to concrete statuary. Follow these tips to reduce winter weathering to your fountain:

- * Disconnect power to pumps and lights.
- * Remove plugs / stoppers in all fountain bowls to open drains and let all moisture out. Keep drains open throughout winter.
- * Place an absorbant material like burlap, blankets, etc. inside vases/bowls and cover all with a Henri fountain cover.
- * Do not allow snow or ice to build up on or against the concrete. Remove snow before it turns to ice. Do not use salt or chemical ice removers as these may damage concrete.